

REPAIR AND REINSTALLATION IN- STRUCTION FOR DEERE NO-TILL COULTER CAM ASSEMBLY

STEP 1


Grind out this area as shown for spring clearance



1

Step 2

Re-Attach cam block as shown below using the 2 holes with two 3/8 bolts and nuts



2